

DIMEXO System Variable — GstarCAD 2027

5349 kbadmin September 26, 2026 [Command Reference](#) 0 5

DIMEXO System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The DIMEXO system variable is used to specify the distance that the extension line offsets origin.

Type	Real
Saved in	Drawing
Initial value	0.0625(Imperial) or 0.6250 (Metric)

The DIMEXO system variable value determines the minimum offset for constant length of extension lines.

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5349>