

DIMFRAC — GstarCAD 2027

DIMFRAC

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The DIMFRAC system variable is used to set the fraction format when DIMLUNIT set to 4 (architectural) or 5(fractional).

Type	Integer
Saved in	Drawing
Initial value	0
Range	0,1,2

System Variable Value:

- 0:** horizontal stacked
- 1:** diagonal stacked
- 2:** not stacked

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)