

DIMLTEX1 System Variable — GstarCAD 2027

5361 kbadmin September 26, 2026 [Command Reference](#) 0 8

DIMLTEX1 System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The DIMLTEX1 system variable is used to set the linetype for the first extension line.

Type	Strings
Saved in	Drawing
Initial value	""

The DIMLTEX1 system variable value is "BYLAYER", "BYBLOCK", or names of linetype.

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5361>