

DIMTSZ System Variable — GstarCAD 2027

5394 kbadmin September 26, 2026 [Command Reference](#) 0 10

DIMTSZ System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The DIMTSZ system variable is used to specify the size of oblique strokes drawn instead of arrowheads for linear, radius, and diameter dimension.

Type	Real
Saved in	Drawing
Initial value	0.0000

System Variable Value:

- 0:** draw arrowheads
- >0:** draw oblique strokes instead of arrowhead. The size of oblique strokes is control by DIMTSZ system variable multiplied by the value of DIMSCALE system variable.

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5394>