

DIMTXSTYD System Variable — GstarCAD 2027

5396 kbadmin September 26, 2026 [Command Reference](#) 0 14

DIMTXSTYD System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The DIMTXSTY system variable is used to specify the dimension text styles.

Type	Strings
Saved in	Drawing
Initial value	Standard

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5396>