

DIMUPT System Variable — GstarCAD 2027

5401 kbadmin September 26, 2026 [Command Reference](#) 0 4

DIMUPT System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The DIMUPT system variable is used to control options for user-positioned text.

Type	Parameter
Saved in	Drawing
Initial value	Off

System Variable Value:

- Off:** cursor only controls the dimension line position
- On:** cursor only controls the dimension line position

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5401>