

DISPSILH System Variable — GstarCAD 2027

5403 kbadmin September 26, 2026 [Command Reference](#) 0 4

DISPSILH System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The DISPSILH system variable is used to control the display of 3D solid object profiles in 2D wireframe or 3D wireframe visible styles.

Type	Integer
Saved in	Drawing
Initial value	0
Range	0,1

System Variable Value:

- 0:** off, hide profiles
- 1:** on, display profiles

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)