

Drag Multiple Lines — GstarCAD 2027

5468 kbadmin September 26, 2026 [Command Reference](#) 0 10

Drag Multiple Lines

[GstarCAD 2027](#) · [Command Reference](#)

You can use the BGMT command to change the row and column width by dragging the line of the table and the corresponding parts of the line will also change. For example, drag the line you selected to the right side and all the lines in the right side will move to the right side correspondingly.

Operation steps:

- 1.Start the command.
- 2.Specify the line of table for dragging.
- 3.Specify the place or distance to drag to (left is positive).
- 4.Enter to finish moving.

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5468>

