

GCADPREFIX System Variable — GstarCAD 2027

5543 kbadmin September 26, 2026 [Command Reference](#) 0 7

GCADPREFIX System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The GCADPREFIX system variable is used to save directory path(if exists) specified by GCAD environment variable and attached with path separator if necessary.
(Read only)

Type	Strings
Saved in	Not saved
Initial value	Unknown

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5543>