

GFNAME System Variable — GstarCAD 2027

GFNAME System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The GFNAME system variable is used to specify the pattern of a gradient fill.

Type	Integer
Saved in	Not saved
Initial value	1
Range	1,2,3,4,5,6,7,8,9

System Variable Value:

- 1: linear
- 2: cylindrical
- 3: inverted cylinder
- 4: spherical
- 5: hemispherical
- 6: curved
- 7: inverted spherical
- 8: inverted hemispherical
- 9: inverted curved

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5553>