

GRIPMULTIFUNCTIONAL System Variable — GstarCAD 2027

5567 kbadmin September 26, 2026 [Command Reference](#) 0 9

GRIPMULTIFUNCTIONAL System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The GRIPMULTIFUNCTIONAL system variable is used to control the access way for multiple function grip option.

Type	Bitcode
Saved in	Registry
Initial value	3
Range	0,1,2,3

System Variable Value:

- 0: the multiple function grip option is disabled
- 1: access multiple function grip option by CTRL to change grip behaviors(cycle change object editing ways by pressing CTRL key)
- 2: access multiple function grip option by displaying grip menu when cursor hovering on grips
- 3: access multiple function grip option by CTRL or displaying grip menu

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5567>

