

Get Selection by Object/Layer — GstarCAD 2027

5587 kbadmin September 26, 2026 [Command Reference](#) 0 5

Get Selection by Object/Layer

[GstarCAD 2027](#) · [Command Reference](#)

The getentlaysel command is used to select entities by entity type and layer.

Operation Steps:

- 1.Start the command.
- 2.Select one object and system will take the object layer as target layer.
- 3.Specify region.
- 4.System will select the objects which are in the same layer and with same entity type automatically.

Other versions with matching text

[2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5587>