

HANDLES System Variable — GstarCAD 2027

5592 kbadmin September 26, 2026 [Command Reference](#) 0 22

HANDLES System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The HANDLES system variable is used to report whether object handles can be accessed by application programs.
(Read-Only)

Type	Integer
Saved in	Drawing
Initial value	on

This system variable is only used to keep the integrity of scripts.

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5592>