

HPMAXLINES System Variable — GstarCAD 2027

5613 kbadmin September 26, 2026 [Command Reference](#) 0 6

HPMAXLINES System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The HPMAXLINES system variable is used to set the maximum of hatch lines generated when hatching.

Type	Real
Saved in	Registry
Initial value	300000
Range	10 ~ 10000000

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5613>