

LUNITS System Variable — GstarCAD 2027

LUNITS System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The LUNITS system variable is used to set the linear units format for creating objects.

Type	Integer
Saved in	Drawing
Initial value	2
Range	1,2,3,4,5

System Variable Value:

- 1: scientific
- 2: decimal
- 3: engineering
- 4: architectural
- 5: fractional

The LUNITS system variable does not affect the unit formats of dimension text. The unit formats is controlled by DIMLUNIT system variable and saved together with dimension styles.

Other versions with matching text

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5688>