

MAGMODE System Variable — GstarCAD 2027

5705 kbadmin September 26, 2026 [Command Reference](#) 0 4

MAGMODE System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The MAGFACT system variable is used to specify the zoom factor of magnifier.

Type	Integer
Saved in	Users-settings
Initial value	4
Range	0,2,4,6

0 **Style:**Region **Shape:**Squre

2 **Style:**Window **Shape:**Squre

4 **Style:**Region **Shape:**Circle

6 **Style:**Window **Shape:**Circle

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5705>