

MATBROWSERSTATE System Variable — GstarCAD 2027

5708 kbadmin September 26, 2026 [Command Reference](#) 0 9

MATBROWSERSTATE System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The MATBROWSERSTATE system variable is used to specify whether the material browser is open or closed.
(Read-Only)

Type	Integer
Saved in	Users-settings
Initial value	0
Range	0,1

System Variable Value:

- 0: off
- 1: on

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5708>