

MAXACTVP System Variable — GstarCAD 2027

5711 kbadmin September 26, 2026 [Command Reference](#) 0 11

MAXACTVP System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The MAXACTVP system variable is used to set the maximum number for active viewports at one time in layout.

Type	Integer
Saved in	Drawing
Initial value	64

The MAXACTVP does not have effect on viewport number for plotting.

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5711>