

MESHTYPE System Variable — GstarCAD 2027

MESHTYPE System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The MESHTYPE system variable is used to specify mesh type created by REVSURF, TABSURF, RULESURF, and EDGESURF commands.

Type	Integer
Saved in	Drawing
Initial value	1
Range	0,1

System Variable Value:

- 0:** create traditional polygon meshes or polyface meshes by REVSURF, TABSURF, RULESURF, and EDGESURF commands
- 1:** create completely function meshes objects by REVSURF, TABSURF, RULESURF, and EDGESURF commands(recommend)

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)