

# MIRR Hatch System Variable — GstarCAD 2027

5721 kbadmin September 26, 2026 [Command Reference](#) 0 11

## MIRR Hatch System Variable

[GstarCAD 2027](#) · [Command Reference](#)

### Function Description:

The MIRR Hatch system variable is used to control how MIRROR reflects hatch patterns.

|               |         |
|---------------|---------|
| Type          | Integer |
| Saved in      | Drawing |
| Initial value | 0       |
| Range         | 0,1     |

### System Variable Value:

- 0:** keep the same direction with hatch pattern
- 1:** mirror hatch pattern direction

### Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5721>