

MTEXTTOOLBAR System Variable — GstarCAD 2027

5729 kbadmin September 26, 2026 [Command Reference](#) 0 11

MTEXTTOOLBAR System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The MTEXTTOOLBAR system variable is used to control the display of text formatting toolbar.

Type	Integer
Saved in	Users-setting
Initial value	1
Range	0,1,2

System Variable Value:

- 0: never display the text formatting toolbar
- 1: display the text formatting toolbar after selecting MTEXT objects
- 2: display the text formatting toolbar when the ribbon is on?not support?

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5729>