

PAPERUPDATE System Variable — GstarCAD 2027

5791 kbadmin September 26, 2026 [Command Reference](#) 0 9

PAPERUPDATE System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The PAPERUPDATE system variable is used to control the display of warning dialog box when trying to plot layout by a different paper size from default configuration files of plotter.

Type	Integer
Saved in	Registry
Initial value	0
Range	0,1

System Variable Value:

- 0:** display warning dialog box if the plotter does not support specified paper size in layout
- 1:** set the drawing to be the size configured for plotter

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5791>