

PLINECONVERTMODE System Variable — GstarCAD 2027

5814 kbadmin September 26, 2026 [Command Reference](#) 0 14

PLINECONVERTMODE System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The PLINECONVERTMODE system variable is used to specify the fit method when converting splines to polylines.

Type	Integer
Saved in	Registry
Initial value	0
Range	0,1

System Variable Value:

- 0:** use linear segments to create polylines
- 1:** use arc segments to create polylines

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5814>