

PLINEGEN System Variable — GstarCAD 2027

PLINEGEN System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The PLINEGEN system variable is used to control the way to generate linetype pattern around the vertices of a 2D polyline.

Type	Integer
Saved in	Drawing
Initial value	0
Range	0,1

This settings is not suitable for the polyline with tapered segments.

System Variable Value:

- 0:** generate the linetype beginning and ending with dash at each vertex of the polyline
- 1:** generate the linetype beginning and ending with dash at each vertex of the polyline

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5815>