

PUBLISHHATCH System Variable — GstarCAD 2027

5850 kbadmin September 26, 2026 [Command Reference](#) 0 6

PUBLISHHATCH System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The PUBLISHHATCH system variable is used to control whether hatch patterns of DWF or DWFx published is treated as a single object.

Type	Integer
Saved in	Registry
Initial value	1
Range	0,1

System Variable Value:

- 0:** when publish DWF or DWFx formats, hatch patterns group is treated as each single object
- 1:** when publish DWF or DWFx formats, hatch patterns group is treated as a single object

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5850>