

Reset Dim Text Value — GstarCAD 2027

5900 kbadmin September 26, 2026 [Command Reference](#) 0 8

Reset Dim Text Value

[GstarCAD 2027](#) · [Command Reference](#)

The DIMREASSOC command is used to restore a measurement value to overridden or modified dimension text.

Command line prompts as follows:

Select object: Select dimension objects with non-associative text or press ENTER to quit

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5900>