

SAVEFILEPATH System Variable — GstarCAD 2027

5908 kbadmin September 26, 2026 [Command Reference](#) 0 9

SAVEFILEPATH System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The SAVEFILEPATH system variable is used to specify the path for automatically saved file directory in current task.

Type	Strings
Saved in	Registry
Initial value	Unknown

Users can also change it in Option dialog box.

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5908>