

SELECTIONPREVIEW System Variable — GstarCAD 2027

5919 kbadmin September 26, 2026 [Command Reference](#) 0 20

SELECTIONPREVIEW System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The SELECTIONPREVIEW system variable is used to control the display of selection preview.

Type	Bitcode
Saved in	Registry
Initial value	3
Range	0,1,2

The object will be highlighted when pickbox cursor rolling over objects. It means this object can be selected by clicking.

System Variable Value:

- 0:** turn off
 - 1:** turn on when there is no active command
 - 2:** turn on when prompts to select objects
- Note:** when the COMMANDPREVIEW is on, it ignores the SELECTIONPREVIEW system variable.

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5919>