

Selection Scale — GstarCAD 2027

5986 kbadmin September 26, 2026 [Command Reference](#) 0 13

Selection Scale

[GstarCAD 2027](#) · [Command Reference](#)

The BGSF function can zoom in and zoom out the whole table base on the point you specified.

Operation steps:

- 1.Start the command.
- 2.Specify the base point for the line of table.
- 3.Move the cursor and the table will zoom.
- 4.Drag to a suitable position and click.

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5986>