

Spline to Line — GstarCAD 2027

5996 kbadmin September 26, 2026 [Command Reference](#) 0 15

Spline to Line

[GstarCAD 2027](#) · [Command Reference](#)

The SPLINE2LINE command is used to convert spline(s) to numbers of straight lines.

Once the command is started, the command line prompts as follows:

Select spline or [Set parameters(S)]: Select spline(s) or input "S" to set parameters

[The line precision/Starting point (S)<1.00>]: Input a new value bigger than 0 to join precision between segment lines

Conversion in a straight line to allow the greatest number of <5000>]: Input a new value smaller than 5000 to number of lines

At first, the system will fit the spline with a segment line which precision (Length) has been specified, if the line's number needed is more than the maximum number, the system will extend the length of the lines by force, using the maximum number of lines to fit the spline.

Select spline or [Set parameters(S)]: Then select the spline(s) to be converted and press Enter to finish the operation

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=5996>