

TSPACEFAC System Variable — GstarCAD 2027

6069 kbadmin September 26, 2026 [Command Reference](#) 0 10

TSPACEFAC System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The TSPACEFAC system variable is used to control the line space for Mtext measured by text height.

Type	Real
Saved in	Not saved
Initial value	1.0000
Range	0.25 ~ 4.0

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=6069>