

# Text Mask — GstarCAD 2027

6078 kbadmin September 26, 2026 [Command Reference](#) 0 8

## Text Mask

[GstarCAD 2027](#) · [Command Reference](#)

The TEXTMASK command is used to place a mask object behind selected text or mtext. The rectangular mask is offset from the text by a specified value.

Command line prompts as follows:

Current settings:Offset factor = 0.500000, Mask type = Solid, Mask color = 150

Select text objects to mask or [Masktype/Offset]: Select an option or text or press ENTER to exit.

Text objects are grouped together with the mask objects so that they are moved, copied and erased together. To update the mask after editing the text, run TEXTMASK again, and select the text item to be updated. The previous mask object is erased and a new one is created.

Masktype:

Mask type currently set to Solid

Specify entity type to use for mask [3dface/Solid] <Solid>: Specify a type to use for mask.

### 3DFACE option

Places a 3D Face behind the text.

### **SOLID option**

Masks with a 2D solid in a specified color.

### **WIPEOUT option**

Places the mask in front of the text.

### **Offset**

Specify offset distance between shielded entity and text object.

Enter offset factor relative to text height <0.500000>: Specify a value, or select points to set the mask size.

## Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=6078>