

To Change the Orientation of the Z Axis of the UCS — GstarCAD 2027

6121 kbadmin September 26, 2026 [Command Reference](#) 0 11

To Change the Orientation of the Z Axis of the UCS

[GstarCAD 2027](#) · [Command Reference](#)

To Change the Orientation of the Z Axis of the UCS

1. Click Tools > New UCS > Z Axis Vector on the main menu.
2. Specify the new origin point.
3. Specifying the point.

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=6121>