

# To Modify the Scale of a Layout Viewport — GstarCAD 2027

6270 kbadmin September 26, 2026 [Command Reference](#) 0 12

## To Modify the Scale of a Layout Viewport

[GstarCAD 2027](#) · [Command Reference](#)

### To Modify the Scale of a Layout Viewport

1. Select the layout viewport that you want to modify.
2. Right-click, and then choose Properties.
3. The Properties palette is displayed, select Standard Scale, and then select a new scale from the list.

### Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=6270>