

To Set Running Object Snaps — GstarCAD 2027

6317 kbadmin September 26, 2026 [Command Reference](#) 0 15

To Set Running Object Snaps

[GstarCAD 2027](#) · [Command Reference](#)

To Set Running Object Snaps

1. On the status bar, right-click the Object Snap button, and choose Settings.

2. In the Drafting Settings dialog box, Object Snap tab, select the object snaps you want to use.

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=6317>