

To Set Up a New Visibility State in a Dynamic Block — GstarCAD 2027

6318 kbadmin September 26, 2026 [Command Reference](#) 0 10

To Set Up a New Visibility State in a Dynamic Block

[GstarCAD 2027](#) · [Command Reference](#)

To Set Up a New Visibility State in a Dynamic Block

You can only use this procedure after a visibility parameter has been added to the block definition.

1. Click Insert tab > Block Definition panel > Block Editor in the ribbon.
2. The Edit Block Definition dialog box is displayed, select the block you want to modify.
3. Click the Block Editor ribbon contextual tab > Visibility panel > Visibility States.
4. The Visibility States dialog box is displayed, click New.
5. The New Visibility State dialog box is displayed, in which you can enter a name for the new visibility state.
6. Select one of the following:
 - Hide All Existing Objects in New State
 - Show All Existing Objects in New State
 - Leave Visibility of Existing Objects Unchanged in New State
- Click OK twice.

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=6318>