

To Set the Current Text Style — GstarCAD 2027

6320 kbadmin September 26, 2026 [Command Reference](#) 0 9

To Set the Current Text Style

[GstarCAD 2027](#) · [Command Reference](#)

To Set the Current Text Style

1. Click Annotation tab > Text panel in the ribbon.
2. Select a text style in the Text Style Control drop-down list to make it current.

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=6320>