

USERS1-USERS5 System Variable — GstarCAD 2027

6393 kbadmin September 26, 2026 [Command Reference](#) 0 9

USERS1-USERS5 System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Type	String
Saved-in	Not saved
Initial value	" "

Provides storage and retrieval of text string data. There are five system variables: USERS1, USERS2, USERS3, USERS4, and USERS5.

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=6393>