

VSFACEHIGHLIGHT System Variable — GstarCAD 2027

6413 kbadmin September 26, 2026 [Command Reference](#) 0 11

VSFACEHIGHLIGHT System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The VSFACEHIGHLIGHT system variable is used to control the display of specular highlights of faces without materials in the current viewport. The greater the value, the larger the highlight.

Type	Integer
Saved in	Drawing
Initial value	-30
Range	-100~100

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=6413>