

XLOADPATH System Variable — GstarCAD 2027

6443 kbadmin September 26, 2026 [Command Reference](#) 0 14

XLOADPATH System Variable

[GstarCAD 2027](#) · [Command Reference](#)

Function Description:

The XLOADPATH system variable is used to create the path for store temporary copy of xref when demand-loading.

Type	Strings
Saved in	Registry
Initial value	Unknown

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2026](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=6443>