

BGRIPSET Command — GstarCAD 2026

6547 kbadmin September 26, 2026 [Command Reference 2026](#) 0 7

BGRIPSET Command

[GstarCAD 2026](#) · [Command Reference](#)

Commands > B Command > BGRIPSET

Function Description:

This command is used to create, remove or reset grips that associated with parameters. This command can display number of grips for the specified parameter and reset them to default position. It can only be used in the Block Editor.

Command Access:

Icon: /
Menu: /
Ribbon: /
Toolbar: /
Command: BGRIPSET
Alias: /

Command Prompts:

Select parameter:

Enter number of grip objects for parameter or reset position [0/1/2/4/Reposition] :

0/1/2/4

Enter the number of grips to display for the parameter. (The number of grips available will vary depending on the type of parameter you selected.)

Reposition

Restore the existing grips in the block definition to their default locations.

Related References?

- [Commands about Dynamic Blocks](#)

Related Tasks?

- [To Set the Number of Custom Grips to Display for a Dynamic Block Parameter](#)

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2027](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=6547>