

BDEPENDENCYHIGHLIGHT System Variable — GstarCAD 2026

8681 kbadmin September 26, 2026 [Command Reference 2026](#) 0 7

BDEPENDENCYHIGHLIGHT System Variable

[GstarCAD 2026](#) · [Command Reference](#)

Function Description:

The BDEPENDENCYHIGHLIGHT system variable is used to control whether the selected parameters, actions, and grips and their dependent objects highlighted or not in block editor.

Type	Integer
Saved in	Registry
Initial value	1
Range	0,1

System Variable Value:

- 0:specify the dependent objects not to be highlighted
- 1: specify the dependent objects to be highlighted

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2027](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=8681>