

BPARAMETERFONT System Variable — GstarCAD 2026

8690 kbadmin September 26, 2026 [Command Reference 2026](#) 0 7

BPARAMETERFONT System Variable

[GstarCAD 2026](#) · [Command Reference](#)

Function Description:

The BPARAMETERFONT system variable is used to set the font used for parameters and actions in block editor.

Type	Strings
Saved in	Registry
Initial value	Arial

Users can specify either a True Type font or a SHX font(such as Verdana or Verdana.ttf). They must add the .shx extension to a font. When specifying an Asian Big Font, using the following naming convention: an SHX file followed by a comma, followed by the Big Font file name(such as txt.shx, Bigfont.shx).

Other versions with matching text

[2023](#) · [2024](#) · [2025](#) · [2027](#)

Online URL: <https://www.kb2.gstarcad.com.my/article.php?id=8690>