
Enter 2D Coordinates

2491 GstarCAD MY /KW November 9, 2021 Workflow 0 2273


Enter absolute coordinate

Absolute coordinates are based on the \underline{UCS} origin (0,0), which is the intersection of the X and Y axis. If you know the precise X and Y values of the point, you can use absolute coordinates.



Enter relative coordinate


The last point entered is used as a base for Relative coordinates and you can use them, if you know the location of a point in relation to the previous point.




Enter Polar Coordinates

When creating objects, you can use absolute or relative polar coordinates (distance and angle) . The distance and the angle separated by an angle bracket (<) when you use polar coordinates to specify a point.

Absolute polar coordinates are based on the origin.



Relative coordinates are based on the last point entered. If you know the location of a point in relation to the previous point, you can use relative coordinates.



Online URL: https://www.kb2.gstarcad.com.my/article.php?id=2491